



9.00" (228.6mm)

Ensure the head of the screw or bolt fits through the large part of this opening!



keyo™  
x armodilo

### Keyo Mounting Instructions

- 01 Print this mounting template at 100%. (Double check by measuring the top holes, they should be 9.00" apart).
  - 02 With non-marking tape, affix the template to the wall or surface you want to mount the kiosk to. Ensure the template is straight by using a level
  - 03 With a sharp pencil or screw end, make a mark in the center of the cross-hairs at **A** & **C**. Ensure the marks are visible when the template is removed.
- Optional:** Install suitable anchors at **A** & **C** as required.
- 04 Install two screws **B** or bolts at **A**. (Ensure the head of the screw or bolt will fit through the large part of the opening.)
  - 05 Do not tighten the screws or bolts all the way down, leave about 0.25" of space between the screw head and the wall or surface
  - 06 Hang the Keyo Backer onto the two screws at **A**, once the Keyo Backer is over the screws it should slide down along the channel coming to rest.
  - 07 Double check to ensure the Keyo Back is level, then install two additional screws **C** at **B** and tighten all screws to secure Keyo.



6.00" (152.4mm)

